

CAR CREEPER

■ PART No.CC2. ■ STOCK No.56224.

PARTS DRAWING

06/2002

ASSEMBLY:

1. Slip the lock washer (C) on to barrel nut (B) and insert into pre-drilled holes in chassis.
2. From bottom side, screw caster into nut until hand tight.
3. Complete the procedure by inserting the hex wrench into the barrel nut recess and tighten.

