


## PARTS LIST FOR SUPERMIG TORCH Models 185.V2, 195, 220.V5, 235.V4




ltem	Part No	Description	ltem	Part No	Description
1	120/722007	Ring nut	10	168.200105	Nozzle, Cylinder TR - 15
2	120/722013	Nut, Liner retainer	10	120/722423	Nozzle, Conical TR - 15
3	120/722305	Lance and Diffuser TB15	11	168.301535	Liner,T, 0.6 - 0.8mm 3mt Steel
5	120/722319	Spring for nozzle	11	120/722689	Liner,T, 1.0 - 1.2mm 3mt Steel
6	120/722326	Insulation, diffuser	13	120/722441	Termination connector
7	120/742172	Torch holder	14	120/742175	Gun plug housing
8	120/722415	Contact tip 0.6mm (AF1)	15	120/722171	Ring nut
8	120/722416	Contact tip 0.8mm(AF1)	16	120/722325	Front torch part
8	120/722552	Contact tip 1.0mm ALLY (AF1)	17	120/722693	Insulation Block, Torch part
8	120/722553	Contact tip 1.2mm ALLY (AF1)			
8	120/722556	Contact tip 0.8mm ALLY			

**NOTE:** It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. **IMPORTANT:** No liability is accepted for incorrect use of product. **WARRANTY:** Guarantee is 12 months from purchase date, proof of which will be required for any claim. **INFORMATION:** For a copy of our latest catalogue and promotions call us on 01284 757525 and leave your full name and address including your postcode.

CHARLES POWER Sole UK Distributor	O1284 757500 O1284 757500 O	www.sealey.co.uk
DOWER     Sole UK Distributor       Scaley Group,     Bury St. Edmunds, Suffolk.	📇 01284 703534	sales@sealey.co.uk

## PARTS LIST FOR Model: SUPERMIG 185.V2



POWER

	35 22 28 39 26 53	7) ()
	c <b>ription</b> entiometer	7
	b,Potentiometer	
	tection, rectifier	
	tifier entiometer	
	ctro-valve	
	b for switch	
06 Wire 10 Swi	e feed PCB tch	
	rmostat	
07 Ligh		
02 Cab		
	ns cable de,fan	
	or,fan	
	e feed motor	
	ictance nsformer	
	inter roller	
37 Kno		
	ndle, sleeve/spacer type	
	hing, cable ing, feeder roller shaft	
	ing, torch fixing	
	cket, counter roller	
	nection, torch cer collar	
	eel (fixed)	
45 Whe		
	stic frame	
	b, counter roller tension cket, axle	
	cket, castor	
02 Bull	nosed adaptor (not shown)	
	ng, counter roller tension	
57 Spri 28 Har	0	
	k panel	
76 Dia	ohragm	
	cket (bottle)	
	nt panel tom (black)	
16 Cov	. ,	
15 Doc	or	
	e, wheel	
	mp, earth d roller 0.6 - 0.8	
30 Clai	mp, earth	

Feed roller 0.6 - 0.8

Regulator (2 gauges) not shown

TORCH

Guide hose

Spindle Kit

Gear set

120/722019

120/742180

120/990097


120/990257

120/990264

REG/MT

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. IMPORTANT: No liability is accepted for incorrect use of product. WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim. INFORMATION: For a copy of our latest catalogue and promotions call us on 01284 757525 and leave your full name and address including your postcode.

SEALE WELDERS	Sole UK Distributor	O1284 757500 O1284 757500 O	www.sealey.co.uk
OLALLE WELDERS	Bury St. Edmunds, Suffolk.	📥 01284 703534	sales@sealey.co.uk



**NOTE:** It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. **IMPORTANT:** No liability is accepted for incorrect use of product. **WARRANTY:** Guarantee is 12 months from purchase date, proof of which will be required for any claim. **INFORMATION:** For a copy of our latest catalogue and promotions call us on 01284 757525 and leave your full name and address including your postcode.

