



Item	Part No.	Description
1	MW200I-01	Top Handle
2	MW140I-02	Case
3	MW140I-03	Main Control PCB
4	MW140I-04	Front Panel Control Board
5	MW160I-05	Front Plastic Panel
6	MW160I-06	Negative Busbar
7	MW140I-07	Front Panel Support Plate (For MW140I)
8	MW200I-08	Potentiometer Knob
9	MW200I-09	Cable & Electrode Holder (Not Shown)
10	MW200I-10	Cable & Earth Clamp (Not Shown)
11	MW200I-11	Quick Socket

Item	Part No.	Description
12	MW160I-12	Support Plate
13	MW160I-13	Positive Busbar
14	MW160I-14	Bottom Panel
15	MW160I-15	Insulation Plate
16	MW160I-16	EMC Board
17	MW160I-17	Support Bracket
18	MW160I-18	Fan
19	MW160I-19	Fan Support
20	MW200I-20	Rear Plastic Panel
21	MW160I-21	Rocker Switch
22	MW160I-22	Power Cable

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. There may be alternative versions of this product, please contact us should you require this information.

IMPORTANT: No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.