



Issue Date:- 130505  
Issue No:- 1



### WIRING DIAGRAM FOR SUPERCHARGE 15/1.V4



ITEM	PART NO	DESCRIPTION
1	120/112318	RECTIFIER
2	120/122400	SWITCH, WHITE ROCKER
3	120.120696	THERMAL SWITCH
4	120.123555	POSITIVE CABLE 1.5mm <sup>2</sup> 1M
5	120.123556	WORK CABLE 1.5mm <sup>2</sup> 1M
7	120/152127	AMMETER
8	120.169349	TRANSFORMER
9	120/322138	BUSHING, CABLE
10	120.322664	FRAME
11	120/712623	POSITIVE CLAMP
12	120/712624	NEGATIVE CLAMP
13	120/802256	FUSE 15Amp BLADE TYPE Pack of 10
14	120/990339	HANDLE (SO)
15	120/990352	FUSE HOLDER
16	120.990934	COVER KIT
17	120.980022	FRONT PANEL KIT