


PARTS FOR:

INDUSTRIAL HYDRAULIC PIPE BENDER WITH STAND 15ton

MODEL: PBS91.V4



ITEM	PART NO	DESCRIPTION	ITEM	PART NO		DESCRIPTION
1	PBS91.V4-01	UPPER PLATE	22	PBS91.V4-	-22	HANDLE SOCKET
2	PBS91.V4-02	PIN	23	PBS91.V4	-23	PIVOT PIN
3	PBS91.V4-03	LOWER PLATE	24	PBS91.V4	-24	SNAP RING
4	PBS91.V4-04	SUPPORTING ROLLER	25	PBS91.V4	-25	HANDLE
5	PBS91.V4-05	STAND	26	PBS91.V4	-26	HANDLE GRIP
6	PBS91.V4-06	BENDING DIE	27	PBS91.V4	-27	STEEL BALL
7	PBS91.V4-07	PUMP BLOCK	28	PBS91.V4	-28	O-RING
8	PBS91.V4-08	PIVOT PIN (SMALL)	29	PBS91.V4	-29	PLUG SCREW
9	PBS91.V4-09	PIVOT PIN (LARGE)	30	PBS91.V4-	-30	RELEASE VALVE
10	PBS91.V4-10	OIL FILLER NUT				
11	PBS91.V4-11	CYLINDER	SPARES DIES (NOT SHOWN)			
12	PBS91.V4-12	CYLINDER END COVER	PBS90 V	√2-31 BI	ENDING	DIF 1/2"
13	PBS91.V4-13	OIL PUMP CORE	PBS90.\		ENDING	
14	PBS91.V4-14	PUMP NUT (LARGE)	PBS90.\		ENDING	
15	PBS91.V4-15	PUMP PISTON PIN (SMALL)	PBS90.			DIE 1-1/4"
16	PBS91.V4-16	PUMP PISTON PIN (LARGE)	PBS90.\			DIE 1-1/2"
17	PBS91.V4-17	PUMP NUT (SMALL)	PBS90.\		ENDING	
18	PBS91.V4-18	OIL PUMP CORE	PBS91.			DIE 2-1/2"
19	PBS91.V4-19	SNAP RING	PBS91.		ENDING	
20	PBS91.V4-20	PIN	. 2001.			
21	PBS91.V4-21	HANDLE SOCKET CONNECTOR				

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. IMPORTANT: No liability is accepted for incorrect use of product.

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.

INFORMATION: For a copy of our latest catalogue and promotions call us on 01284 757525 and leave your full name and address, including postcode.









