




PARTS FOR: **AIR SHEARS PISTOL TYPE** MODEL:SA56



<u>ITEM</u>	PART NO	DESCRIPTION	<u>ITEM</u>	PART NO.	DESCRIPTION	<u> </u>
1	SA56.01	HOUSING	21	SA56.21	PLANET GEAR	
2	SA56.02	AIR INLET	22	SA56.22	WORKING SPINDLE	
3	SA56.03	EXHAUST DIFFUSER	23	SA56.23	BEARING	
4	SA56.04	O-RING	24	SA56.24	INTERNAL GEAR	
5	SA56.05	O-RING	25	SA56.25	GEAR CASE	
6	SA56.06	TRIGGER PIN	26	SA56.26	WASHER	
7	SA56.07	VALVE BUSHING	27	SA56.27	ECCENTRIC NUT	
8	SA56.08	O-RING	28	SA56.28	WASHER	
9	SA56.09	VALVE SPINDLE	29	SA56.29	WASHER	
10	SA56.10	TRIGGER	30	SA56.30	CUTTER HOUSING	
11	SA56.11	SCREW	31	SA56.31	BLADE, RIGHT	
12	SA56.12	O-RING	32	SA56.32	BLADE, LEFT	
13	SA56.13	BEARING	33	SA56.33	BLADE, CENTER	
14	SA56.14	REAR END PLATE	34	SA56.34	BUSHING	
15	SA56.15	CYLINDER	35	SA56.35	LOCK NUT	
16	SA56.16	ROTOR	36	SA56.36	LOCK SCREW	
17	SA56.17	ROTOR BLADES(5PCS)	37	SA56.37	SPRING	
18	SA56.18	FRONT END PLATE	38	SA56.38	PIN	
19	SA56.19	BEARING		SA56.39	HEX KEY (NOT SHOW	N)
20	SA56.20	GEAR PIN				

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. **IMPORTANT:** No liability is accepted for incorrect use of product.

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.

INFORMATION: For a copy of our latest catalogue and promotions call us on 01284 757525 and leave your full name and address, including postcode.









