

Issue: 3
Date: 011002

Fig. 1

Item	Part No.	Description
1	PDM170F-1-01	Screw, HS M6 x 1.0-10
2	PDM170F-1-02	Collar, Rack
3	PDM170F-1-03	Gear, Helical
4	PDM170F-1-04	Crank
6	PDM170F-1-06	Table
7	PDM170F-1-07	Clamp, Table
8	PDM170F-1-08	Screw, HH M16 x 20-35
9	PDM170F-1-09	Arm, Table cw Scale
10	PDM170F-1-10	Base
11	PDM170F-1-11	Support, Column
12	PDM170F-1-12	Screw, HH M10 x 1.5-40
13	PDM170F-1-13	Screw, HS M10 x 1.5-12
14	PDM170F-1-14	Tube, Column
15	PDM170F-1-15	Rack
16	PDM170F-1-16	Clamp, Column
17	PDM170F-1-17	Support, Table cw Indicator
18	PDM170F-1-18	Worm, Elevation
19	PDM170F-1-19	Pin, Gear

Fig. 2

Item	Part No.	Description
1	PDM170F-2-01	Nut, Lock
2	PDM170F-2-02	Ring, Locking
3	PDM170F-2-03	Washer
4	PDM170F-2-04	Bearing, 17mm
5	PDM170F-2-05	Washer, Rubber
6	PDM170F-2-06	Tube, Quill
7	PDM170F-2-07	Key, Chuck
8	PDM170F-2-08	Chuck
9	PDM170F-2-09	Arbor
10	PDM170F-2-10	Key, Drift
11	PDM170F-2-11	Spindle
12	PDM170F-2-12	Bearing

Fig. 3

Item	Part No.	Description
1	PDM170F/3/01	Ring, Retaining
2	PDM170F/3/02	Bearing, 25mm
3	PDM170F/3/03	Spacer, Bearing
4	PDM170F/3/04	V Belt, M24
5	PDM170F/3/05	Nut, Pulley
6	PDM170F/3/06	Pulley, Spindle
7	PDM170F/3/07	Insert, Pulley
8	PDM170F/3/08	Guard, Pulley cw Labels
9	PDM170F/3/09	Screw, RH M6 x 1.0-16
10	PDM170F/3/10	Screw, Set M10 x 1.5-12
11	PDM170F/3/11	Pulley, Motor
13	PDM170F/3/13	Screw, PH M5 x 0.8-12
14	PDM170F/3/14	Pivot, Idler
15	PDM170F/3/15	Pulley, Centre
16	PDM170F/3/16	Bearing, 15mm
18	PDM170F/3/18	Washer, Foam
19	PDM170F/3/19	Lock Washer, External M6
20	PDM-MS	Micro Switch



01284 757500



01284 703534

E-mail: sales@sealey.co.uk
Web: www.sealey.co.uk




Fig. 4

Item	Part No.	Description
1	PDM170F-4-01	Knob, Motor Adjustment
2	PDM170F-4-02	Screw, SS M10 x 1.5-12
3	PDM170F-4-03	Handle, Belt Tension
4	PDM170F-4-04	Pin, Stop
5	PDM170F-4-05	Depth Stop Ring
6	PDM170F-4-06	Lock Depth Screw
7	PDM170F-4-07	Hub
9	PDM170F-4-09	Handle
10	PDM170F-4-10	Bolt
11	PDM170F-4-11	Lock Washer, M5
12	PDM170F-4-12	Screw, PH M5 x 0.8-8
13	PDM170F-4-13	Switch Box
14	PDM170F-4-14	Screw, PH M5 x 0.8-8
15	PDM170F-4-15	Switch, No Volt
16	PDM170F-4-16	Bolt
21	PDM170F-4-21	Screw, SS M10 x 1.5-27
22	PDM170F-4-22	Hex. Nut, M10
23	PDM170F-4-23	Spring Seat
24	PDM170F-4-24	Spring Retainer
25	PDM170F-4-25	Spring, Torsion
26	PDM170F-4-26	Spring Cap

Fig. 4 Continued

Item	Part No.	Description
27	PDM170F-4-27	Hex. Nut, M12
28	PDM170F-4-28	Head
29	PDM170F-4-29	Clip, Chuck Key
35	PDM170F-4-35	Screw, PH M6 x 1.0-12
36	PDM170F-4-36	Clamp, Cord
37	PDM170F-4-37	Motor Bracket Support
38	PDM170F-4-38	Screw, HH M8 x 1.25-20
39	PDM170F-4-39	Washer
40	PDM170F-4-40	Motor Mount
42	PDM170F-4-42	Hex. Nut, M12
43	PDM170F-4-43	Motor
44	PDM170F-4-44	Hex. Nut, M12
45	PDM170F-4-45	Lock Washer
46	PDM170F-4-46	Motor Bracket Support
47	PDM170F-4-47	Screw, HH M8 x 1.25-16
48	PDM170F-4-48	Adjusting Lever
49	PDM170F-4-49	Terminal Box
50	PDM170F-4-50	Cover, Terminal Box
51	PDM170F-4-51	Capacitor
52	PDM170F-4-52	Terminal Block
53	PDM170F-4-53	Screw



01284 757500



01284 703534

E-mail: sales@sealey.co.uk

Web: www.sealey.co.uk