

INSTRUCTIONS FOR: AIR CAULKING GUN

Model: AK41.V2

Thank you for purchasing a Sealey product. Manufactured to a high standard this product will, if used according to these instructions and properly maintained, give you years of trouble free performance



IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS AND CAUTIONS. USE THIS PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. PLEASE KEEP INSTRUCTIONS SAFE FOR FUTURE USE.

1. SAFETY INSTRUCTIONS

- □ WARNING! Disconnect the gun from the air supply before changing accessories, servicing or performing any maintenance.
- Maintain the gun in good condition. Replace or repair damaged parts. Use recommended parts only. Unauthorised parts may be dangerous and will invalidate the warranty.
- Keep children and unauthorised persons away from the work area.
- Avoid unintentional operation.
- Ensure caulking compound manufacturer's instructions are carefully followed.
- DO NOT hold gun or attachments close to your face (especially eyes, ears, etc.) and do not point gun or air hose at other persons or animals.
- DO NOT carry by the air hose, or yank the hose or the gun from the air supply.
- DO NOT use the gun for any purpose other than that for which it is designed.
- DO NOT operate the gun if damaged.
- When not in use disconnect from the air supply and store in a safe, dry, childproof area.

SPECIFICATION

Cartridge	215 x 50mm
Air Supply	30 - 40psi
Air Consumption	15cfm
Air Inlet	1/4"BSP



AIR SUPPLY

For recommended hook-up, see below right.

- Ensure air valve is in "off" position before connecting to the air supply.
- An air pressure of no more than 40psi and an air flow of 15cfm will be required. 32
- WARNING! Ensure that the air supply does not exceed 40psi. Too high a pressure will shorten the product life and may П be dangerous, causing damage and/or personal injury.
- 3.3. Drain air supply tank daily. Water in the air line will damage the gun and will invalidate your warranty.
- Clean compressor air inlet filter screen weekly. 34
- Line pressure should be increased to compensate for unusually long air hoses (over 8 metres). Minimum hose and fittings bore should be 10mm.
- Keep hoses away from heat, oil and sharp edges. Check hoses for wear and make certain that all connections are secure.

WATER AIR SEPARATOR SUPPLY QUICK COUPLER Office and **NIPPLE** DRAIN DAILY RECOIL REGULATOR HOSE

OPERATING INSTRUCTIONS

- ☐ WARNING! Ensure you read, understand and apply the safety instructions in Section 1 and follow any manufacturer's instructions on the caulking container.
- Screw the gun cylinder A to the gun body.
- Unscrew the end cap B from the cylinder and insert the caulking cartridge. Screw on the end cap B to retain the cartridge.
- Ensure air supply is regulated to no more than 40psi (2.75 bar) and then attach air hose to the gun.
- Aim the nozzle of the cartridge into a safe area and depress the gun trigger to check for correct operation.

DECLARATION OF CONFORMITY

Declaration of Conformity We, the sole importer into the UK, declare that the product listed here is in conformity with the following standards and directives.

Air Caulking Gun Model AK41.V2

The construction file for this product is held by the manufacturer and may be inspected, by a national authority, upon request to Jack Sealey Ltd.

98/37/FC Machinery Directive 93/68/EEC CE Marking Directive Signed by Mark Sweetman

Date: 12th March 2002

For Jack Sealey Ltd. Sole importer into the UK of Sealey Power Products.

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. IMPORTANT: No responsibility is accepted for incorrect use of this product.

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.

INFORMATION: For a copy of our latest catalogue and promotions call us on 01284 757525 and leave your name and address, including postcode.



Sole UK Distributor,



01284 757500



01284 703534

E-mail: sales@sealey.co.uk