

Thank you for purchasing a Sealey product. Manufactured to a high standard this product will, if used according to these instructions and properly maintained, give you years of trouble free performance.

▲ IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS AND CAUTIONS. USE THIS PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAIL URE TO DO SO MAY CAUSE DAMAGE OR PERSONAL INJURY, AND WILL VALIDATE THE WARRANTY. PLEASE KEEP INSTRUCTIONS SAFE FOR FUTURE USE.

## . SAFETY INSTRUCTIONS

- P WARNING! Disconnect blow gun from the air supply before changing accessories, servicing or performing any maintenance. De-pressurise the blow gun before removing air hose from the gun.
- 3 Maintain the blow gun in good condition (use an authorised service agent).
- 3 Replace or repair damaged parts. Use genuine parts only. Non genuine parts may be dangerous and will invalidate the warranty.
- 3 Keep the work area clean, uncluttered and ensure there is adequate lighting.
- 3 Only use the blow gun for the purpose of blowing compressed air.
- WARNING! Always wear approved eye or face protection when operating the blow gun. Use a face or dust mask if dust is generated. Wear appropriate protective clothing.
- 3 Maintain correct balance and footing. Ensure the floor is not slippery and wear non slip shoes.
- 3 Remove ill fitting clothes, ties, watches, rings, other loose jewellery, and contain/tie back long hair.
- 3 Keep children and unauthorised persons away from the working area.
- 3 Secure non stable work piece with a clamp, vice or other adequate holding device.
- 3 Avoid unintentional starting.
- p WARNING! air pressure should not exceed 8bar.
- 3 Keep air hose away from heat, oil and sharp edges. Check air hose for wear before each use, and ensure that all connections are secure.
- 7 DO NOT use the blow gun for any purpose other than for which it is designed.
- 7 DO NOT operate blow gun if any parts are damaged or missing as may cause failure or personal injury.
- 7 DO NOT carry the by the hose, or yank the hose from the air supply.
- 7 DO NOT allow untrained persons to operate the blow gun.
- 7 DO NOT operate blow gun when you are tired, under influence of alcohol, drugs or intoxicating medication.
- 7 DO NOT leave the blow gun operating whilst unattended.
- 7 DO NOT direct air from the blow gun at yourself, others or animals
- 3 When not in use disconnect from the blow supply and store in a safe, dry, child proof area.

## 2. OPERATING INSTRUCTIONS

Connect to an air supply which has an 8 bar output. Take the unpressurized air hose and connect it to the blow gun inlet. Turn the air supply on, depress the gun trigger to release the flow of compressed air. Declaration of Conformity We, the BLOW GUN sole importer into the UK, declare that the prod-Models SA918 & SA919 ucts listed here are in conformity with the following EEC standards and directives 891/392EEC 91/368/EEC The construction files for these ( ( products are held by the manufac-93/44/EEC turer and may be inspected on 93/68/FEC request by contacting Jack Sealey I td Signed by Mark Sweetman 17th February 2000 For Jack Sealey Ltd. Sole importer into the UK of Sealey as logo

**NOTE:** It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

IMPORTANT: No liability is accepted for incorrect use of product.

**WARRANTY:** Guarantee is 12 months from purchase date, proof of which will be required for any claim.

**INFORMATION:** Call us for a copy of our latest catalogue and promotions on 01284 757525 and leave your full name and address including your postcode.

Sole UK Distributor. Sealey Group, Bury St. Edmunds, Suffolk. O1284 757500

🛓 01284 703534

E-mail: sales@sealey.co.uk