



INSTRUCTIONS FOR:

PLATFORM TRUCKS

CST992.V2 MODELS CST991.V2 CST993.V2

Thank you for purchasing a Sealey product. Manufactured to a high standard this product will, if used according to these instructions and properly maintained, give you years of trouble free performance.



IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. PLEASE KEEP INSTRUCTIONS SAFE FOR FUTURE USE.

1. SAFETY INSTRUCTIONS

- Always load evenly with the centre of gravity of the load as near the centre of the truck as possible.
- Obtain additional support for large or wide loads to prevent tipping.
- X Do not overload the truck see Specifications.
- Do not leave unattended, especially when loaded, unless the wheels are chocked or the truck is otherwise secured.
- Do not use truck on uneven ground and do not run over curbs or steps use a ramp.
- Do not allow others to ride on the truck.
- Do not use the truck if any part is significantly damaged pay particular attention to the wheels.

SPECIFICATIONS

	CST991.V	CST992.V2	CST993.V2
Max. Load	150kg.	300kg.	250kg
Wheel Diameter	100mm .	125mm .	
Deck Length/Width/Height	.725/465/140mm.	.910/605/209mm.	.949/496/226mm
Overall Height	815mm.	863mm.	961mm

3. ASSEMBLY & USE

Numbers/letters in brackets refer to those on the relevant parts diagrams below.


3.1 CST991 & CST992


- Remove the bolts and washers (C) from the underside corners of the deck and use them to attach the wheels (A, B). 311
- Two wheels are swivel castors (B), these should be fitted at the handle end of the deck. Note!
- To fold down the platform truck handle frame (CST991.V2, CST992.V2 only) push down the release bar (D) and fold the handle over the base, release bar when in place.

3.2 **CST993**

- 3.2.1 Remove the bolts (C) and washers (D) from the underside corners of the deck and use them to attach the wheels (A, B).
- Two wheels are swivel castors (B), these should be fitted at the handle end of the deck. Note!
- Remove the two bolts (F) from the ends of the handle frame (G). 3.2.2
- Locate the ends of the handle frame in the sockets in the deck frame and retain with the screws. 3.2.3

4. PARTS





NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. IMPORTANT: No liability is accepted for incorrect us e of product.

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.

INFORMATION: For a copy of our latest catalogue and promotions call us on 01284 757525 and leave your full name and address, including postcode.



Sole UK Distributor Sealey Group, Bury St. Edmunds, Suffolk.



11284 757500



www.sealey.co.uk

